

# PERFORATEDWINDOWSIGNS.COM

## INSTALLATION INSTRUCTIONS

Please read and follow these instructions. Perforated vinyl is somewhat delicate, please handle vinyl carefully. Complete instructions are also available on line at [www.PerforatedWindowSigns.com](http://www.PerforatedWindowSigns.com) and if you have any other questions about installing any of our products please call our office at 800-422-4231.



STEP 1. Clean surface area thoroughly with denatured alcohol for best results, other window cleaners can be used also. Dry working area completely with paper towel or cloth.



STEP 2. With masking tape, tack graphic on glass as shown. Always double check measurements before applying. Masking tape on center top and bottom will be used to create a center hinge.



STEP 3. Remove masking tape carefully from left and right side. Gently fold over either side onto its self. Form a gentle crease. Larger applications may require two people.



STEP 4. Gently peel perforated material away from liner as shown.



STEP 5. Cut liner with a scissors or razor blade (do not tear liner) and discard.



STEP 6. Gently apply perforated material with squeegee, always squeegee from center to outer edges.



STEP 7. Gently squeegee, be careful material can tear easily if perforated.



STEP 8. Gently squeegee, be careful material can tear easily if perforated.



STEP 9. After one side is down, remove masking tape carefully and fold remaining side onto the other side as shown.



STEP 10. Remove remaining liner and discard. Make sure not to let graphic stick to its self.



STEP 11. Gently squeegee down the rest of the graphic.



STEP 12. Gently squeegee down the rest of the graphic.



STEP 14. Finished.



STEP 15. View from the inside, as you can see almost invisible.